



# RDMC-800

## Professional Hybrid Controller



Anodized Aluminum Integrated Case



Large 3.2 Inch Graphical LCD



3D-AXIS Accurate Joystick



Full Function with 37 Buttons & 9 Rotary



Special Features with PGU



Supports Various Protocols & Interfaces





# Contents

Safety Note .....	2
Contact Us .....	2
Features .....	3
Specification .....	4
Dimensions .....	4
Technical Specification .....	4
Physical Specification .....	4
Port Pinout .....	5
Buttons Function .....	6
Display Summary .....	8
Setting Items .....	9
Cameras Setting .....	9
Ports Setting .....	9
LAN Setting .....	9
Video Switch Setting .....	9
Device Setting .....	9



## RDMC-800 User Manual

This documentation describes how to use Radicson RDMC-800 device.

## Copyright Notice

Copyright© Radicson Technology Inc. All rights reserved.

## Documentation Version 1.0

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual, or otherwise, without the prior written permission of Radicson Inc.

## Safety Notices

Before using RDMC-800 device, please ensure that you read and understand the safety precautions below:


- Do not attempt to open the case of RDMC-800 or modify it in any way, as this will void the warranty.
- Keep the RDMC-800 away from water and other liquids, as this may cause the unit to malfunction.
- RDMC-800 may become warm during use. This does not indicate malfunction.

## Contact Us


- If you encounter any problem when using our products, please contact us by [support@radicson.com](mailto:support@radicson.com) and we will serve you with utmost satisfaction.
- We'll offer a satisfying discount on batch purchase and affiliate program. If you are interested, please contact us by [info@radicson.com](mailto:info@radicson.com) email address.

# Features

- Controls up to 8 Cameras via RS-232 / RS-422 / RS-485 Interface
- Supports Sony Visca, Pelco-D, Pelco-P and Panasonic Protocols
- Pan, Tilt and Zoom Controlling with speed definition for P/T/Z separately
- All camera settings can be accessed through the OSD menu from joystick
- Adjustment camera settings (Focus, IRIS, WB and etc.) via specific keys
- 16 Presets directly call and supports up to 255 presets
- Large and ergonomic joystick for accurate and convenient camera control
- Controls External/GPU video switcher simultaneously




# Specification



Interface	4x RJ-45 RS-232/422/485 1x RJ-45 Ethernet (LAN) 1x RJ-45 External Video Switcher 1x Phoenix 8-Pin RS-232/422/485
Protocol	Visca, Pelco-D, Pelco-P, Panasonic
Number of Camera	Up to 8 Camera
Number of Preset	16 Direct Button, 255 Preset Per Cam
Joystick	3D-AXIS (Pan/Tilt/Zoom)
Display	3.2" Graphical Color LCD
Adjustment Function	Auto/Manual Focus with Gain Pan/Tilt/Zoom Speed Gain Brightness, IRIS, Red/Blue Gain White Balance (Auto, OnePush)
Body	Anodized Aluminum


Button	8x Setting Push-Button 8x Camera Push-Button 5x Image Push-Button 16x Preset Push-Button
Rotary	1x Manual Focus Adjust 3x Pan/Tilt/Zoom Speed 1x Brightness Level 1x Iris Adjust 1x White Balance Adjust 2x Red/Blue Amount
Input Voltage	DC 5V - 2A
Power	8W (Max)
Temperature	-20C ~ 50C
Weight	1.84 Kg
Size	361mm x 198mm x 44mm

# Port Pinout



① Reset Button	Reset all setting and load factory default setting	Micro Push Button																																									
② USB Port	Use for upgrade and install / change firmware	USB 2.0 Type A																																									
③ Ethernet (LAN)	Ethernet port connect to network switch or connect to Radicson PGU (Auto Tracking System) directly	RJ45 Standard Network Port (Ethernet/LAN)																																									
④ Ext. Switcher Port	RJ45 port to connect and control external video switcher / matrix / mixer through Serial or IR signal	 <table border="1" data-bbox="1209 1099 1485 1211"> <thead> <tr> <th colspan="8">Ext. Switcher (RJ45)</th> </tr> <tr> <th>1</th><th>2</th><th>3</th><th>4</th><th>5</th><th>6</th><th>7</th><th>8</th> </tr> <tr> <th colspan="3">Serial 1</th><th colspan="3">Serial 2</th><th colspan="2">IR</th> </tr> <tr> <th>TX</th><th>RX</th><th>GND</th><th>TX</th><th>RX</th><th>GND</th><th>+</th><th>-</th> </tr> </thead> </table>	Ext. Switcher (RJ45)								1	2	3	4	5	6	7	8	Serial 1			Serial 2			IR		TX	RX	GND	TX	RX	GND	+	-									
Ext. Switcher (RJ45)																																											
1	2	3	4	5	6	7	8																																				
Serial 1			Serial 2			IR																																					
TX	RX	GND	TX	RX	GND	+	-																																				
⑤ Camera Port Channel 1 (Phoenix-8Pin)	Connect to camera and control it through RS-232 / RS-422 / RS-485 signal by Visca / Pelco-D / Pelco-P / Panasonic Protocols. (Channel 1 Phoenix port internally connected to Channel 1 RJ45 port)	 <table border="1" data-bbox="1209 1272 1485 1424"> <thead> <tr> <th colspan="8">Camera Channel 1 (Phoenix-8Pin)</th> </tr> <tr> <th>1</th><th>2</th><th>3</th><th>4</th><th>5</th><th>6</th><th>7</th><th>8</th> </tr> <tr> <th colspan="4">RS-232</th><th colspan="4">RS-422 / RS-485</th> </tr> <tr> <th>TX</th><th>RX</th><th>GND</th><th>TX+</th><th>TX-</th><th>GND</th><th>RX+</th><th>RX-</th> </tr> <tr> <td colspan="4"></td><td colspan="4" style="text-align: center;">A+ B-</td><td></td> </tr> </thead> </table>	Camera Channel 1 (Phoenix-8Pin)								1	2	3	4	5	6	7	8	RS-232				RS-422 / RS-485				TX	RX	GND	TX+	TX-	GND	RX+	RX-					A+ B-				
Camera Channel 1 (Phoenix-8Pin)																																											
1	2	3	4	5	6	7	8																																				
RS-232				RS-422 / RS-485																																							
TX	RX	GND	TX+	TX-	GND	RX+	RX-																																				
				A+ B-																																							
⑥ Camera Port Channel 1 to 4 (RJ45)	Connect to camera and control it through RS-232 / RS-422 / RS-485 signal by Visca / Pelco-D / Pelco-P / Panasonic Protocols. (Channel 1 Phoenix port internally connected to Channel 1 RJ45 port)	 <table border="1" data-bbox="1209 1473 1485 1626"> <thead> <tr> <th colspan="8">Camera Channel 1 - 4 (RJ45)</th> </tr> <tr> <th>1</th><th>2</th><th>3</th><th>4</th><th>5</th><th>6</th><th>7</th><th>8</th> </tr> <tr> <th colspan="4">RS-232</th><th colspan="4">RS-422 / RS-485</th> </tr> <tr> <th>TX</th><th>RX</th><th>GND</th><th>TX+</th><th>TX-</th><th>GND</th><th>RX+</th><th>RX-</th> </tr> <tr> <td colspan="4"></td><td colspan="4" style="text-align: center;">A+ B-</td><td></td> </tr> </thead> </table>	Camera Channel 1 - 4 (RJ45)								1	2	3	4	5	6	7	8	RS-232				RS-422 / RS-485				TX	RX	GND	TX+	TX-	GND	RX+	RX-					A+ B-				
Camera Channel 1 - 4 (RJ45)																																											
1	2	3	4	5	6	7	8																																				
RS-232				RS-422 / RS-485																																							
TX	RX	GND	TX+	TX-	GND	RX+	RX-																																				
				A+ B-																																							
⑦ Power ON/OFF Button	Power ON and OFF device	2-Step Button																																									
⑧ Power Input Jack	DC Input Jack 5V - 2A	Power Jack																																									

# Buttons Function




① PAN SPEED	Camera horizontal movement speed (1 ~ 10)
② TILT SPEED	Camera vertical movement speed (1 ~ 10)
③ ZOOM SPEED	Camera zoom movement speed (1 ~ 10)
④ JOYSTICK	3D-Axis Joystick, push left/right for pan move, up/down for tilt move, turn right/left for zoom in/out, push button for call camera home position. * in joystick menu, up/down for move across items, right for goto submenu (enter), left as back, turn left/right for change item value
⑤ MENU Button	Enter joystick menu and show items in lcd
⑥ OSD Button	Enable/disable camera menu on output display * when enabled, you can move across menu item through joystick (4)
⑦ ADD/PRST Button	<u>ADD Function</u> : when the number of cameras is more than 8, for select camera number > 8, press ADD button and use number 0 to 9 from preset buttons (27) as camera number (you can input 2-digit number) <u>PRST Function</u> : when PGU is connected to joystick, call camera position of specific microphone directly without turning it on, use number 0 to 9 from preset buttons (27) as microphone number (you can input 3-digit number)
⑧ SW Button	When external switcher is connected to joystick, select switcher video input source through camera number buttons (14) as switcher input number.
⑨ LCD	3.2 inch graphical TFT LCD display



⑩ PGU Button	When connected to PGU (Auto Tracking System) through ethernet (LAN) port, take the PGU to Auto/Manual mode * in manual mode, auto track is disabled and you can control all cameras that connected to PGU directly from joystick
⑪ MIC Button	When PGU connected, turn on and off microphones from joystick directly through number 0 to 9 from preset buttons (27) (can input 3-digit number) * Some microphone models not supported
⑫ SET/ON Button	<u>SET Function</u> : set current position of selected camera for direct call through preset buttons (15) <u>ON Function</u> : when PGU connected and mic button activated (11), turn on selected microphone number (through number 0 to 9 from presets buttons)
⑬ RST/OFF Button	<u>RST Function</u> : Reset selected direct call preset button (15) for selected camera <u>ON Function</u> : when PGU connected and mic button activated (11), turn off selected microphone number (through number 0 to 9 from presets buttons)
⑭ CAMERA Buttons	Select camera number to control
⑮ PRESET Buttons	16 buttons to set and call camera preset directly for each camera * 0 to 9 buttons use for enter number in some functions (27)
⑯ AUTO IRIS Button	Active auto iris mode on selected camera for automatically adjusts the iris (aperture) in order to regulate and optimize the amount of light camera receives
⑰ IRIS Rotary	Adjustment iris (aperture) of selected camera manually
⑱ BRIGHTNESS Rotary	Adjustment brightness of selected camera manually
⑲ BLC Button	Enable/Disable Backlight compensation (BLC) of selected camera
⑳ OPWB Button	One-push white balance, Fill the camera frame with what you know to be a white object, This is saved as the camera's "white" reference (used in conditions where AWB (22) is unable to detect white balance correctly)
㉑ GAIN Rotary	Adjustment gain of selected camera manually
㉒ AWB Button	Adjustment white balance of selected camera automatically
㉓ BLUE Rotary	Adjustment blue color amount of selected camera manually
㉔ RED Rotary	Adjustment red color amount of selected camera manually
㉕ AUTO Focus Button	Adjustment correct focus of selected camera automatically
㉖ FOCUS Rotary	Adjustment focus near/far of selected camera manually
㉗ Input Number Buttons	Button 0 to 9 of preset buttons used for input the number in some functions * can input 1-digit/2-digit/3-digit number depending on the condition

# Display Summary



① Camera Number	The number of selected camera	Camera 1 to 8
② Camera Port	The connection port of selected camera	Port 1 to 4 / PGU
③ PGU Status	The status of connection to PGU	Connected / Disconnected
④ Ext. Switcher Channel	The channel number of external switcher / matrix (if connected to joystick)	Channel 1 to ... (dependent on switcher model)
⑤ Current Function	Display current function (last function disappear after 4s)	Joystick function (PT,Z) Each Button & Rotary Function
⑥ Microphone Queue	When connected to PGU, Display the queue of activated microphones	The IDs of activated microphones
⑦ Pan Speed	Camera horizontal movement speed	1 to 10
⑧ Tilt Speed	Camera vertical movement speed	1 to 10
⑨ Zoom Speed	Camera zoom movement speed	1 to 10



# Setting Items

C.C.J I Setting
Cameras Setting
Ports Setting
LAN Setting
Video Switch Setting
Device Setting

Cameras Setting	Camera 1 to 8 Setting	Connection: Port 1 to Port 4 / PGU Protocol: Visca Preset / Visca Position Pelco-D / Panasonic ID Number: ID-1 to ID-8 Video Switch: SW-1 to SW-8
Ports Setting	Port 1 to 4 Setting	(for port 1 to port 4 separately) Connection: RS-232 / RS-422 / RS-485 Baud Rate: 300, 600, 1200, 2400, 4800, 9600, 14400, 19200, 38400, 56000, 57600, 115200
LAN Setting	Ethernet LAN Configuration	IP Add: xxx.xxx.xxx.xxx Subnet: xxx.xxx.xxx.xxx Gateway: xxx.xxx.xxx.xxx PGU IP: xxx.xxx.xxx.xxx
Video Switch Setting	External Switcher/Mixer Model	Select from supported models (supported models will be updated over time)
Device Setting	Device 1 Setting / Device 2 Setting	(Reserve)
	Hardware Setting	Buzzer Status: ON/OFF LCD Backlight: -----o----- (bar)
	Reset Factory	Reset device to factory setting
	About Device	Software and Hardware Version Serial Number